SLIDE THE SCREEN SHUT BUY DUIL

KEEP OUT PESTS WITH THE ECONOMICAL FLEXSCREEN-SLIDE MODEL




resh air ventilation, sunlight, improved visibility and increased security are in! And so is employee comfort and improved productivity.

The easy to install FlexScreen slider can be attached under the header, or mounted to the inside wall with a bracket to allow the screen to be opened beyond the door frame and completely out of the doorway.

Both models feature a simple to use manual roller & track system that allows the FlexScreen to slide smoothly from side to side. Hook and loop fasteners and side seams reinforced with a steel bar completely seal the sides of the FlexScreen and also provide for easy opening and closing. FlexScreen is made from durable, allweather vinyl coated polyester which is fire retardant as well as mildew and UV resistant.

The inside wall mount model also incorporates a brush to seal the top against insects.



Quick Notes:

Quality

- Safety strips sewn into curtain for screen visibility
- Brush made from durable nylon fibers; brush hardware is extruded aluminum
- Nylon rollers; galvanized track; coated steel wall brackets.
- Vertical stiffeners, velcro and magnets are used to tightly seal the sides and allow for easy opening.

Practicality


- Keeps out insects & birds, reduces dust & wind, improves sanitation
- Lets in fresh air and light
- Improves employee comfort and productivity
- Economical to buy and maintain
- Easy to install
- Increases security a visual and physical barrier to reduce theft & pilferage
- Can be custom ordered to fit almost any opening

Use the FlexScreen-Slide at Loading Docks, Garages, Waste Areas and Food Processing Facilities. Keep out birds and bugs and let in sunlight and fresh air!

SLIDE FLEXSCREEN INSTALLATION & ACCESSORY HARDWARE

Hook Rollers are

hooks mounted on



Standard Track is straight

roller track formed from

Side Wall
Brackets are coated steel angle for years of trouble-free service and are used to attach inside wall mounting.

Wall Mount Brush is made from nylon fibers. It's used with inside wall mount to seal the top of the FlexScreen – keeping out insects, dust and other contaminants. Extends from top of track over to wall.

